MANOMAY

4G PROTECT PRO
Pan-Tilt Camera

MANOMAY

USER MANUAL

In The Box

**Dome Camera x 1no.**　　　**12V DC Power Adapter**

Screw Pouch x 1　　　　**User Manual Card x 1no.**

1. 3MP 4G Protect Pro Pan-Tilt Camera

8 Antenna

7 Base

Lens **1**

6 Speaker

LDR **2**

3

5 MIC

Infrared & Spot Light

4

Reset Button - SD Card/SIM Card Slot

Interface Description

1. 3MP 4G Protect Pro Pan-Tilt Camera

1 Light Sensor

Reset
Button   Network Port &
2 **5**   Indicator Light

4 DC Power
Supply (12V, 1A)

SD Card Slot **3**   **6** SIM Card Slot

Micro SD

SIM   Reset
Button

Description

1. Light Sensor

The light Sensor detects the ambient luminance. The infrared light will be turned on when lux level drops below 3.

2. Reset Button

During the working state of device, press the Reset Button for 3-5 seconds. This will restore the factory default settings of the camera once you hear voice prompt annunciation.

3. SD Card Slot

Insert SD Card for video storage.

4. DC Power Supply

Connect 12V, 1A DC Power supply

5. SIM Card Slot

Insert 4G SIM Card.

4G Camera Cable Light Status :

1. Slow Flashing :

If the 4G module or SIM card is abnormal, the light flashes once every 2s.

2. Fast Flashing :

If the 4G Signal is poor or not available the light flashes once every 0.5s.

3. Steady On :

If the network is normal the light is on continuously.

● APP Download and Installation :

Users can search "Manomay App" on APP Store or PlayStore. You can also install the app by scanning the below QR codes.

Manomay
Android App

Manomay
iOS App

Note: The app requires iOS 9.0 version / Android 5.0 or above

Software Installation

• Account Login :

On the Login interface, input account/
phone number/email, & the corresponding
password, and click the "OK" button to log in.

You can also login through OTP.

Third-party login : "Manomay App" supports
third-party login. Click Experience it icon
to jump to the "Manomay App" and complete
the authorization and log in.


Installing the SIM Card

1. When the device is
   powered OFF, Insert a
   4G SIM card that can
   access the internet into
   the device;

Note : Please check the SIM & SD card slots and insert the SIM and SD card
in proper positions and directions. Make sure the SIM card is activated
with an appropriate data plan.

Adding the Camera in App

1. Open the APP and click on the "+" icon on the upper right corner to enter the scan code interface


2. Click on Scan to Add

3. Scan the QR code available on the camera


4. On the search device interface

5. Please wait patiently while the device get configure.

6. Set the name for your device. click on confirm to "ADD" the device successfully

7. After set the device name click on finished

When the QR code on the device is not available or does not work follow the below instructions.

1. Click on "Camera ID ADD"

2. Enter the device ID and password and click on confirm to "ADD" the device successfully

1. To add the camera using wired connectivity

Note : Please remove the 4G SIM card before using the above configuration method.

1. Power ON the device. Connect it to a router with internet access using a network cable. Scan the QR code of the device

2. Set the name for your device. click on confirm to "ADD" the device successfully

2. Method

1. When the mobile phone and the device are connected to the same network, select "LAN Scan"

2. After searching for the device click Add and "Password" Click on Confirm

• Installation Method

4G Mini PT Camera
3.1 Wall Installation
1) Use the camera positioning proper to locate and punch holes. Insert the rubber plugs.
2) Align the hole of the camera bracket with the rubber plugs and fasten the bracket to the wall.

3.2 Installation on a wall Pass the metal hoop through the camera bracket hole and mount the camera on the wall.

Ceiling

Wall

Wall Installation

3.2 Installation on a Pole
Pass the metal hoop through the camera bracket hole and mount the camera on the pole.

Recommendation
Install the camera
about 2.5-3M

PIR is sensitive to hot and cold disturbances,
Please note:

Avoid installing the camera where the air flow is agitated. For eg: the air outlet of the air conditioner, the heat dissipation port of the equipment, the side of the fan, the vicinity of the curtain, etc.Please do not install the camera in front of the glass or mirror. The height of the camera installation should be 2.5M-3M, the best distance of PIR trigger.

Do not install the camera upside down.

WARNING

In case of fire or lighting, please don't put product in damp and raining place. Operate or maintain only according to the user manual.

Be careful when you see an attachment with the Dangerous Voltage Sign which might cause serious electric accident

Warning	
⚡	**Warning** CAUTION RISK OF ELECTRONIC SHOCK DO NOT AOPEN ⚠️
Warning	To reduce electric shock, unprofessional people please don't open product front panel or rear panel

Warning

In case of electric shock and fire Please don't use power supply beyond power list in user manual

Notice

1. Ensure your equity, Please read the user manual carefully before you use the product

2. Please contact professional people if you need install and maintain the product.

3. Working Environment : temperature of-20^{0}C~+60^{0}C, relative humidity under 85%

4. Please do not exceed the standard range of temperature, humidity and voltage as suggested in the user manual.